




Zipbolt Straight Slipfix Kit




1 Mark position of 10mm 3/8" hole onto end of rail. As an alternative to marking hand rails for drilling, the Railbolt Drill Guide is available making it fast and easy.




4 Assemble the shaft and gear housing into the rail.




2 Mark and bore 25mm 1" and 10mm 3/8" holes as indicated.



5 To mark the centre of the keyhole disc measure 28mm 1 1/8" upwards from the bottom of the rail position. Using a 25mm 1" bit bore hole into post 7mm 9/32" deep so the keyhole disc is flush or slightly under. Secure disc with screws.



3 Mark fully final position of the handrail onto post observing the centre line.



6 The shaft should be flush or under the surface of the rail end. Using a 5mm hex bit in a tool or Allen wrench fitted into the gear housing the shaft can be moved to engage into the disc keyhole. Then simple push rail downwards and tighten.

Making your life easier!